



# Motorhome Applications



Vehicle	Year	Front	Notes	Rear	Notes
<b>Beaver</b>					
Magnum Air 8 bag		see Safari			
Gillig Chassis		90-2164SP1			
<b>Bluebird Wanderlodge</b>					
LX, Lxi, Forward Control	01-	90-2497SP1	A	9005-1025	
Tag axle (non-steerable)				8805-1010	
Tag Axle (steerable)				8805-1015	
M380, 450LXi	02-	9044-1005		8844-1006	D
Tag axle				8844-1007	
<b>Chevrolet</b>					
P30 / P32 / P3500	68-99	8805-1006	F	8805-1007	
<b>Country Coach</b>					
Affinity, Concept, Magna, MAT					
<i>Gillig Chassis w/Neway</i>		90-2164SP1	A	88-1668SP1	
<i>Ridewell Suspension</i>		90-1968SP1		9005-1025	
<i>Neway IFS</i>	99	8805-1012		8805-1013	
Allure, Intrigue					
<i>Gillig Suspension</i>		90-2164SP1			
<i>Neway IFS</i>		8805-1012		8805-1013	
<i>Reyco Suspension</i>		88-1458SP1		88-1457SP1	
<b>Eagle</b>					
Model 10		90-1898	C	90-1898	B
Tag axle				90-1898	B
<b>Featherlite</b>					
Vogue III w/ Crown chassis		90-1867		90-1868	
Vogue	99			90-1943SP4	
Tag Axle				80-1490	
<b>Ford</b>					
E-350, E450	92-05	82-2553		82-2554	
F53 Super Duty V8	88-98	8805-1018		88-1668SP1	
F53 Triton V10	99 +	8805-1018		8805-1019	
<b>Foretravel</b>					
U225, U-240 w/ velvetride	91-95	88-1490SP2		90-2256SP1	C
U-280, U-300, U320 Series		8805-1010	D	8805-1010	D
Tag axle				8805-1011	
<b>Freightliner</b>					
FL 60 w/airliner rear susp.				8805-1022	E
XC w/rigid front axle	93-	8805-1020		8805-1022	
XC w/ Neway IFS	93-07	8805-1012		8805-1022	
XC w/ZF IFS (55° wheel cut)	03-07			8805-1022	
XCS - steel leaf spring only		88-1668SP1			
<b>GMC</b>					
C5500		8805-1023		8805-1002	
Classic Bus		90-2575		90-2576SP1	
RTS Bus		90-2433SP1		90-2434SP2	
P3500 Class A-Motorhome		8805-1006		8805-1007	
<b>Monaco</b>					
Dynasty/Executive/Signature/Windsor					
4 shocks/axle (pin/eye)	03-06	8805-1016	D	8805-1017	D
4 shocks/axle (eye/eye)	93-02	8805-1004	D	8805-1005	D
10 Bag Coach	93-06	8805-1004	D	8805-1005	D
4 Bag (2 shocks/axle)	02-05	8805-1021		8805-1022	

Vehicle	Year	Front	Notes	Rear	Notes
<b>Motor Coach Industries</b>					
D - Coach		90-2586	F	90-2587	F,D
Tag axle				90-2588	F
E-Coach		90-2755		9005-1018	
				9005-1019	
J-Coach		90-2816		9005-1018	
Tag axle				9005-1019	
<b>Peak Chassis</b>					
Alpine Coach		8805-1021		8805-1022	
<b>Prevost</b>					
H3, XL w/ rigid front axle		90-2572		90-2573	D
Tag axle				90-2573	
H3, XL, XLII w/ IFS		90-2574		90-2573	D
Tag axle				90-2573	
<b>Safari</b>					
Magnum Air 8 Bag	96-00	8805-1004SP	D	8805-1005SP	D
Magnum Air 4 Bag	92-01	88-1490SP2		88-1458SP2	
Magnum w/velvetride	95-00	88-1490SP2		88-1458SP2	
Magnum w/leaf spring	93-99	8805-1010		88-1458SP2	
Ridewell Frt, RAD 227 Rr		90-1968		90-1868	
Reyco 1212 Frt, 102AR Rr		88-1458SP1		88-1457SP1	
<b>Spartan</b>					
Alpine/Summit	97-01	8805-1012		8805-1022	
MC 2000	91-95	8805-1021		88-1457SP1	
Mountainmaster I-Beam	96-04	8805-1021		8805-1009	
Mountainmaster IFS under 13000		8805-1008		8805-1009	
K2, K3		90-2815		8805-1009	
tag axle				8805-1013	
<b>Sprinter</b>					
2500 w/ 2.4 L engine	-05	87 2604		82 2434	
2500 all other	-05	87 2638		82 2434	
3500	-05	87 2638		82 2440	
<b>Workhorse</b>					
P30/P32/Widetrack IFS	00-05	8805-1006		8805-1007	
W16-W18	05+	8805-1001		8805-1003	
W20-W24	99-03	8805-1001		8805-1003	
W20-W24	04+	8805-1001		8805-1002	

- |                       |                                 |
|-----------------------|---------------------------------|
| A. Adjust 1 full turn | D. Requires [4] shocks per axle |
| B. Adjust 1.5 turns   | E. Requires Kit FL60 spacer kit |
| C. Adjust to Maximum  | F. Special Order                |

Revised: 4/11/07